



SHORTCUT SHEET

ETalk

QuickTime™ and a
TIFF (Uncompressed) decompressor
are needed to see this picture.

The E-talk CS8400 has been designed specifically for those people who require a dedicated communication device.

TO USE

Charger port is on right hand side.

Far left inset button is mode button (on right hand side of device). You must press this once to get the programming icon to come up in the message window.

1. Click on programming icon
2. Click on button to program
3. Click on modify key
4. Click on label
5. Click on keyboard
6. Type label on keyboard
7. OK
8. OK
9. Click on Message
10. Click on keyboard
11. Type message
12. OK
13. OK
14. Click on symbol
15. Click on search
16. Type in one word
17. OK

- 18. OK
- 19. OK

To power down for a weekend or for any longer period of time, click on programming icon, any button, and click on shut down then yes.

To find master page: click on programming icon, any button, open page, then start page, OK.

PRODUCT INFORMATION

Operating System: Windows CE Embedded (dedicated) **Display:** 8.4" Poly-silicon (LTPS) touch screen (viewable outdoors) **Resolution:** 800 x 600
Dimensions: 9.3" x 7.7" x 1.8" **Weight** 3.6 lbs **Battery:** Rechargeable 3700mAh Lithium Ion (8 hours of use) **Speaker:** Loud 2W Internal Speaker

Pricing \$4,699.00 with E-talk 3 Software \$5,595.00 with Enkidu Impact

CONTACT INFORMATION

www.GreatTalkingBox.com
The Great Talking Box Company
2245 Fortune Drive, Suite A
San Jose, CA 95131
United States
Toll Free: 1-877-ASK-4GTB
or: 1-877-275-4482
Phone: 1-408-456-0133
Fax: 1-408-456-0134

Edited (Created) by Julie Ford, Academy 20, Dec. 15 2006

For more SWAAAC Shortcut Sheets, go to www.swaaac.org, click on **AT Loan Bank** and then click on **Shortcut Sheets**. Would you like a Shortcut Sheet that doesn't exist? Contact the SWAAAC office at (303) 315-1276 or sarah.barthel@uchsc.edu.